



Stock Code: F430D
Fermod Inside Release Deflector
Material: 304 Grade
Stainless Steel, #4 Polish

Install instructions

The F430D Fermod Inside Release Deflector

Designed to prevent accidental damage to the F430 Inside Release by deflecting impacts from carts or trolleys out and away from the inside release handle.

1. The F430 Inside release handle should be installed and operational.
2. Mark both the centres of the deflector and inside release handle as pictured
3. Mark the door blade 35mm from the end of green release paddle as pictured.
4. Line up both centres of the deflector and inside release handle and mark your 1st rivet hole and mount.
5. Level the deflector, ensuring that the centres are level and fix remaining rivets

Additional Information

CRH & All manufacturers highly recommend that all internal safety release mechanisms fitted to doors are checked at least 3 times weekly to ensure they are functioning correctly.



**For enquiries, please e-mail info@crh.com.au
or call us at 1300 274 287**